TECHNOLOGY**CORE**"

Installing TeamBoard Drivers on MOE V2.0

- 1. Log on to the computer locally with the Administrator or OC log on.
- 2. Right click My Computer and go to Properties.



3. Now go to the Advanced tab then click on Environment Variables at the bottom.

System Properties			? 🗙				
Sustem Bestore	Automa	tic Undates	Bemote	Environ	ment Varia	bles	? 🗙
General Comp	outer Name	Hardware	Advanced	- User v	ariables for Ad	ministrator	
You must be logged on a Performance Visual effects, processo	as an Administrat or scheduling, me	or to make most of emory usage, and v	these changes. virtual memory	Vari TEM TMP	able P	Value %USERPROFILE%\Local Settings\Temp %USERPROFILE%\Local Settings\Temp	
User Profiles Desktop settings relate	d to your logon	(S <u>e</u> ttings	Syster	n variables able	New Edit Delet	
Startup and Recovery- System startup, system	failure, and debu	ugging information	Settings	Com FP_f NUM OS Path	Spec NO_HOST_C IBER_OF_P	C:\WINDOWS\system32\cmd.exe NO 4 Windows_NT C:\Program Files (x86)\Windows Resour New Edit Delet	. >
E	nviro <u>n</u> ment Varia	ables Erro	r Reporting			OK Ca	ncel
	OK	Cance	Apply				



- 4. Now you will get another box pop up. In the first area with the white space there will be two Variables. One is TEMP and the other is TMP.
- 5. Please make a note of the two Values in each Variable.
- 6. Once you have the two Variables written down, highlight each Variable and click Edit.
- 7. Delete the Variable value for each one and enter C:\Temp.

Edit User Variabl	e ? 🔀
Variable <u>n</u> ame:	ТЕМР
Variable <u>v</u> alue:	C:\Temp
	OK Cancel

- 8. Click OK and then OK on the System Properties.
- 9. Insert the TeamBoard CD and run the setup.exe (The installation diagrams are from TeamBoard Suite Version 4.21. If you have Version 5.0 or 5.5, the setup is very similar.).
- 10. When the setup begins, the following screen will be displayed.

T Welcome		×
	Welcome	
	This program will install the TeamBoard software Select the Next button to begin the installation. You can select the Cancel button now if you do not want to install the software at this time	
	< Back Next > Cancel Help	



- 11. Click Next at the Welcome screen.
- 12. Click Accept at the License Agreement.



- 13. Install the software into the default location. This should be C:\Programs Files.
- 14. If you are installing your applications into C:\LocApps you can install it into here.

T Directory					
	Select Destination Directory				
	Please select the directory where the TeamBoard files are to be installed				
	C:\Program Files\TeamBoard Browse				
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	,				
	< <u>B</u> ack [ <u>Next</u> >] Cancel Help				

15. At the Select Controller screen select the correct item for your TeamBoard. For this installation the TeamBoard used is the H Series USB controller

T Select controller	
	Please select the controller type for
	TeamBoard
	H-Series, USB A-Series, Serial H-Series, Serial
	< <u>B</u> ack <u>Next</u> > Cancel Help

## TECHNOLOGY**CORE**"

16. Click Next and then Next again at the Ready to Install screen.



17. Now the Installation progress bar will be displayed.

Installing		
	23%	

18. Click Finish once the setup is complete.



19. At the Reboot screen, click Yes.





- 20. Once the computer has rebooted, log back in as the Local Administrator.
- 21. The Start Menu shortcuts should now be installed.

	🚺 Dashboard
	Draw
	👔 Help
	Recorder
	🏭 Virtual Keyboard
🛅 TeamBoard	🕥 Virtual Mouse

22. Now down in the System Tray near the clock, the Red TeamBoard 'T' Icon should be installed.



- 23. At this point connect the TeamBoard USB cable into the computer and let it install the drivers.
- 24. Once the drivers are installed, right click on the Red TeamBoard 'T' Icon and go to Calibrate ► Interactive.

Dashboard	
✔Enabled Mode →	
Calibrate 🔹 🕨	Whiteboard
Draw	Action Bar
Annotate	Interactive
Virtual Keyboard	
Virtual Mouse	
Redetect PnP devices	
Help	
About	

25. Now you have to press the white board where all the cross points are.

## TECHNOLOGY**CORE**"



26. When this is completed, the TeamBoard has been configured and you can start using TeamBoard Draw.

- 27. Once the TeamBoard is all setup and working you will need to go back into the Environment Variables and change the two Variables TEMP and TMP back to the original settings noted earlier.
- 28. This completes the installation guide for installing TeamBoard on MOE V2.0.